

UR100D

Akku-Rasentrimmer 10,8V



Pos.	Artikel-Nr.	PG	Bezeichnung	Stk.
1	458505-8	18	Griff vorne	1
2	921387-6	1	Sechskantschraube M5x65	1
3	458260-2	7	Griffhalter	1
4	264072-1	1	Feststellknopf M6	1
5	144939-8		Rohr 28 kpl.	1
5,1	808723-2	1	Hinweisschild	1
5,2	816F56-7		Hinweisschild	1
6	458256-3	7	Hülse	1
6,1	252103-8	2	Mutter M5-8	2
7	911243-8	1	Kombi-Schraube M5x25	1
8	458257-1	2	Hebel	1
9	319667-6	2	Stift 9	1
10	911258-5	1	Kombi-Schraube M5x35	1
11	458258-9	4	Rohrkappe	1
12	135952-7	23	Rohr 24 kpl.	1
13	266326-2	1	Schraube 4x18	6
14	183H91-5	21	Motorgehäuse inkl. 15	1
15	183H91-5	21	Motorgehäuse inkl. 14	1
16	421940-3	1	Kappe	1
17	629315-2	27	Motor	1
18	688131-1	1	Filter	1
19	424567-8	1	Gummihülse 24	1
20	327065-0	4	Kabelschutz	1
21	213021-5	1	O-Ring 5	2
22	135950-1	21	Blattschutz-Set	1
23	922234-4	1	Innen-6 Kant-Schraube M5x20	2
24	346555-4	1	Messer	1
25	266427-6	1	Schraube 4x12	1
26	854A93-3		Typenschild UR100D	1
27	266326-2	1	Schraube 4x18	6
28	183H89-2	22	Griff-Set inkl. 39	1
28,1	263002-9	1	Gummistift 4	4
29	699113-8	17	Zuleitung	1
30	632L22-0	1	Führung	1
31	620780-8	32	Elektronik	1
32	650744-8	9	Schalter D3V-16-3C26	1
33	231473-8	1	Druckfeder 4	1
34	452438-9	1	Schalterentriegelung	1
35	231473-8	1	Druckfeder 4	1
36	458259-7	3	Schalthebel	1
37	644813-5	13	Kontaktplatte	1
38	854B01-0		Serien-Nr.-Schild UR100D	1
39	183H89-2	22	Griff-Set inkl. 28	1
39,1	263002-9	1	Gummistift 4	4

UR100D

Akku-Rasentrimmer 10,8V

