

# CP100D

## Akku-Universalschere 10,8V



Pos.	Artikel-Nr.	PG	Bezeichnung	Stk.
1	266404-8	1	Blechschraube 3x14	6
2	183G66-8	21	Gehäuse-Set inkl. 11	1
3	853H53-4	1	Typenschild CP100D	1
4	251574-6	1	Schraube 3x24	2
5	126614-8	25	Getriebe inkl. Motor	1
6	251571-2	3	Schraube M4+8	1
7	457828-1	10	Messerabdeckung	1
9	266385-6	1	Blechschraube 4x14	1
11	183G66-8	21	Gehäuse-Set inkl. 2	1
12	231469-9	2	Druckfeder 4	1
13	457829-9	3	Einschaltsperr	1
14	233438-6	1	Druckfeder 4	1
15	457830-4	3	Schalthebel	1
16	650744-8	9	Schalter D3V-16-3C26	1
17	620687-8	31	Elektronik	1
18	644813-5	13	Kontaktplatte	1
19	853H60-7	1	Serien-Nr.-Schild CP100D	1
20	688165-4	1	Filter	1

## \*\*\* Zubehör \*\*\*

Z	144620-1		Untermesser	1
Z	197334-1		Ladegerät DC10WC 10,8V	1
Z	197394-3		Akku-BL1020B Li 10,8V 2,0Ah	1
Z	198589-1		Werkzeugtasche	1
Z	198603-3		Segmentmesser	1

# CP100D

## Akku-Universalschere 10,8V

