


Model No.CP100D CORDLESS MULTI CUTTER



Model No.CP100D CORDLESS MULTI CUTTER

Obj. č.	Obj. č.	Popis	Možnost záměny	Množství	Nový/Starý	Poznámka 1	Poznámka 2
001	266404-8	TAPPING SCREW BIND 3X14		6			
002	183G66-8	HOUSING SET		1		obal	
002		INC. 11					
003	853H53-4	CP100D NAME PLATE		1			
004	251574-6	TAPPING SCREW BIND 3X24		2			
005	126614-8	GEAR ASSEMBLY		1		p	
006	251571-2	- FLAT HEAD SCREW M4X8		1			
007	457828-1	BLADE COVER		1		kryt no	
008	198603-3	MULTI CUTTER BLADE SET		1			
009	266385-6	TAPPING SCREW 4X14		1			
010	144620-1	UNDER BLADE COMPLETE		1	*	spodn	
010-1	1410C9-5	UNDER BLADE COMPLETE	O	1		spodn	
011	183G66-8	HOUSING SET		1		obal	
011		INC. 2					
012	231469-9	compression spring 4		1		compression spring 4	
013	457829-9	LOCKOFF LEVER		1		p	
014	233438-6	COMPRESSION SPRING 4		1		pru	
015	457830-4	SWITCH LEVER		1		p	
016	650744-8	SWITCH D3V-16-3C26		1		vyp	
017	620687-8	CONTROLLER		1		regulace CP100D	
018	644813-5	TERMINAL		1		terminal	
019	853H60-7	CP100D SERIAL NO. LABEL		1			
020	688165-4	LINE FILTER		1		st	
A01	***DC10WC	DC10WC BATTERY CHARGER		1	*		
A01		COMPO-PARTS			*		
A01-1	***DC10WD	DC10WD BATTERY CHARGER	<	1			
A01-1		COMPO-PARTS					
A02	197394-3	BATTERY BL1020B SET		1	*		
A02-1	197396-9	BATTERY BL1021B SET	<	1	*		
A02-2	197396-9	BATTERY BL1021B SET	O	1			
A03	198589-1	TOOL BAG SET		1			
F05	198968-3	BATTERY BL1016 SET		1	*		
F06	198969-1	BATTERY BL1016 SET (2PIECES)		1	*		
F07-1	198970-6	BATTERY BL1021B SET (2PIECES)	O	1	*		
F08-1	199002-2	BATTERY BL1041B SET (2PIECES)	O	1	*		

Prosím uveďte objednací číslo dílu v objednávce

Datum tisku 17. 10. 2024