



Model No. UC3041A 300MM ELECTRIC CHAIN SAW



Model No. UC3041A 300MM ELECTRIC CHAIN SAW



Model No.UC3041A 300MM ELECTRIC CHAIN SAW

Obj. č.	Obj. č.	Popis	Možn ost zá měny	Množ ství	Nový/ Starý	Poznámka 1	Poznámka 2
001	266326-2	šroub 4x18=new265995-6		3	*		
001-1	265B67-9	TAPPING SCREW 4X18	O	3			
002	454725-2	REAR COVER		1		kryt ES34TLC ES39TL C ES43TLC UC3041A UC3541A UC4041A	
003	191972-1	uhlíky CB-132 = old CB-115, 6601 91972		1	*		
003-1	194984-3	CARBON BRUSH SET CB-132	O	1		uhl	
004	682211-5	guma		2		guma	
005	815A73-4	UC3041A NAME PLATE		1			
006	424600-6	FRONT GRIP		1		p	
007	266388-0	TAPPING SCREW 5X16		1	*		
007-1	265D74-4	TAPPING SCREW 5X16	O	1			
008	253807-5	podložka 5		1		podlo	
009	142279-8	FRONT HAND GUARD COMPLETE		1		p	
C10	802K54-7	INDICATION LABEL		1			
010	231640-5	pružina		1		pru	
011	187869-0	HOUSING SET		1		obal stroje UC3041A UC3541A UC4041A	
C10	802G51-9	CAUTION LABEL		1			
011		INC. 62					
012	650577-1	SWITCH SD-006-BB2AA-AA		1		vyp	
013	650716-3	SWITCH TGC31B		1		vyp	
014	233173-6	pružina UC3020A-Serie		1	*		
014-1	233194-8	Druckfeder 4	O	1		pru	
015	416178-3	aretační tlačítko UC3020A=old22 5144010		1	*		
015-1	413B17-0	LOCK OFF BUTTON	<	1		areta	
016	455185-1	SWITCH LEVER		1		p	
017	645149-5	NOISE SUPPRESSOR		1		kondenz	
018	266326-2	šroub 4x18=new265995-6		2	*		
018-1	265B67-9	TAPPING SCREW 4X18	O	2			
019	687124-5	držák kabelu		1		dr	
020	682540-6	ochr. průchodka 9,3-90=old6825 03-2		1	*	ochr. pr	
020-1	682574-9	průchodka=old225152010	O	1		pr	
021	665876-8	POWER SUPPLY CORD 1.0-2-0.6		1		kabel	
022	210029-0	BALL BEARING 608ZZ		1			
023	681644-1	izolační podložka		1		izola	
024	594538-0	stator UC3020A		1	*		
C10	654069-2	Receptacle		2	*		
C20	654208-4	RECEPTACLE		1	*		
024-1	593869-4	FIELD ASS'Y 220-240V	O	1	*	stator= old594538-0	
C10	654069-2	Receptacle		2	*		
C20	654208-4	RECEPTACLE		1	*		
024-2	590103-3	FIELD ASS'Y 220-240V	O	1	*		
C10	654086-2	RECEPTACLE		2	*		
C20	654199-9	RECEPTACLE		1	*		
024-3	593869-4	FIELD ASS'Y 220-240V	O	1		stator= old594538-0	
C10	654069-2	Receptacle		2			

C20	654208-4	RECEPTACLE		1		
025	266389-8	TAPPING SCREW 5X70		2	*	
025-1	265D35-4	TAPPING SCREW 5X70	O	2		
026	513893-1	ARMATURE ASS'Y 220-240V		1	*	
026		INC. 22,23,29			*	
026-1	511A83-6	ARMATURE ASS'Y 220-240V	S	1		rotor ES34TLC = old 511A83-6
026-1		INC. 22,23,29				
028	419238-0	deska vzduchového chlazení UC3020A-Serie		1		deska vzduchov
029	211061-7	kuličkové ložisko 6000LLB		1		kuli
030	227153-2	pastorek 12 UC3020A-Serie		1		pastorek 12 UC3020A-Serie = old 660227153
031	931403-6	matka M8		1		matka M8
032	142282-9	TANK CAP COMPLETE		1		v
034	454729-4	OIL TANK		1		olejov
037	424602-2	OIL TUBE		1		hadi
038	231975-4	pružina DCS230T/UC3020A=old021245060		1		pru
039	416274-7	víčko DCS230T/UC3020A=old021245100		1		v
040	268238-5	PIN 5		1		
041	158047-9	deska UC3020A-Serie		1		deska UC3020A-Serie
042	233175-2	přítlačná pružina		1		p
044	266326-2	šroub 4x18=new265995-6		1	*	
044-1	265620-9	TAPPING SCREW FLANGE 4X18	S	1		
045	267195-4	podložka DCS230T/UC3020A-Serie		1	*	podlo
046	168321-7	BRAKE BAND		1		p
047	346739-4	BRAKE RING		1		krou
048	231817-2	pružina 5 UC3020A = 660231817ES		1		pru
049	454720-2	BEARING HOUSING		1	*	sk
049-1	413J59-2	BEARING HOUSING	S	1		pouzdro lo
050	213017-6	O RING 6		1		o krou
051	266326-2	šroub 4x18=new265995-6		4	*	
051-1	265B67-9	TAPPING SCREW 4X18	O	4		
052	424601-4	CONNECTOR		1		kryt ES39TLC
053	135615-5	SPUR GEAR 43 ASS'Y		1		hnac
055	210106-8	kuličkové ložisko		1		kuli
056	961006-2	segrovka S-10		1		segrovka S-10= old. 257408-1
057	210033-9	ložisko 696ZZ		1		lo
058	326359-0	ROD		1		ty
060	266326-2	šroub 4x18=new265995-6		2	*	
060-1	265B67-9	TAPPING SCREW 4X18	O	2		
061	345651-5	ozubený doraz		1		ozuben
062	187869-0	HOUSING SET		1		obal stroje UC3041A UC3541A UC4041A
C10	802G51-9	CAUTION LABEL		1		
062		INC. 11				
063	266326-2	šroub 4x18=new265995-6		7	*	
063-1	265B67-9	TAPPING SCREW 4X18	O	7		

064	221526-1	řetězka UC3520A		1		
065	259036-8	STOP RING E-8		1		krou
066	266007-8	Tapping Screw Bind PT3x1=old320266007		3		Tapping Screw Bind P T3x1=old320266007
067	454727-8	TENSION COVER		1		kryt nap
068	454726-0	DIAL 30		1		regula
069	326360-5	SHAFT		1		h
070	227496-2	ozubené kolo UC3020A=old226213320		1		ozuben
071	227496-2	ozubené kolo UC3020A=old226213320		1		ozuben
072	324620-9	šroub UC3020A = old 226213310		1		
073	346740-9	TENSION SLIDE		1	*	
073-1	346859-4	TENSION SLIDE	<	1		nap
074	424603-0	GROMMET		1		
075	196419-0	OIL PUMP SET		1	*	
075		INC. 76			*	
075-1	142156-4	OIL PUMP COMPLETE	<	1	*	olejov
075-2	142156-4	OIL PUMP COMPLETE	O	1		olejov
076	221427-3	WORM GEAR		1		n
077	266326-2	šroub 4x18=new265995-6		1	*	
077-1	265B67-9	TAPPING SCREW 4X18	O	1		
078	266427-6	TAPPING SCREW 4X12		3		
079	142281-1	SPROCKET COVER COMPLETE		1		krytES34TLC ES39TLC ES43TLC UC3041A UC3541A a UC4041A
C10	802E36-3	INDICATION LABEL		1		
080	454728-6	COVER		1		kryt
081	142235-8	NUT COMPLETE		1		up
082	804G74-3	SOUND 104DB LABEL		1		
A01	158024-1	držák=old970102050		1		
A02	165245-8	GUIDE BAR 12		1	*	
A02-1	165245-8	GUIDE BAR 12	O	1		
A03	419288-5	kryt pro UC3020/3520A		1	*	
A03-1	419288-5	kryt pro UC3020/3520A	O	1		
A04	196740-7	SAW CHAIN SET		1	*	
A04-1	511291746	SAW CHAIN 3/8LP.043" L46 CC D	O	1	*	
A04-2	196740-7	SAW CHAIN SET	O	1	*	
A04-3	191H01-8	SAW CHAIN 12 SET	O	1		
F04	196740-7	SAW CHAIN SET		1	*	
F04-1	191H01-8	SAW CHAIN 12 SET	O	1		

Prosím uveďte objednáčíslo dílu v objednávce

Datum tisku 06. 11. 2024