



Model No. UC3051A ELECTRIC CHAIN SAW 300MM



Model No. UC3051A ELECTRIC CHAIN SAW 300MM



Model No.UC3051A ELECTRIC CHAIN SAW 300MM

Obj. č.	Obj. č.	Popis	Možn ost zá měny	Množ ství	Nový/ Starý	Poznámka 1	Poznámka 2
001	931403-6	matka M8		1		matka M8	
002	227626-5	SPIRAL BEVEL GEAR 12		1		pastorek	
003	211111-8	kuličkové ložisko 6301LLB		1		kuli	
004	240003-4	Fan 80		1		v	
005	517904-4	ARMATURE ASS'Y 240V		1		rotor ES2131 ES2136 ES2141 ES2146 UC30 50A UC3051A UC355 0A UC3551A UC4050 A	
005		INC. 3,4,6,7					
006	681666-1	podložka ES-2130A = old 970805 620		1		podlo	
007	210084-2	BALL BEARING 629ZZ		1	*		
007-1	210330-3	BALL BEARING 629ZZ	O	1			
008	266095-5	šroub 5x55		2			
009	419410-4	plastová přepážka ES-2130A =old 226118010		1		plastov	
010	636394-3	FIELD 240V		1	*	stator UC3551A=new 520156-8	
010-1	520156-8	FIELD ASS'Y 240V	<	1		stator UC3551A =old 636394-3	
C10	654020-2	RING TERMINAL F. CB-152,153		2		pru	
C20	654501-6	CONNECTOR P-1.25		2		konektor=new65455 5-3	
C30	654207-6	RECEPTACLE		1			
011	650577-1	SWITCH SD-006-BB2AA-AA		1		vyp	
012	142348-5	MOTOR HOUSING COMPLETE		1		obal motoru UC3051 A UC3551A UC4051A UC4551A	
C10	643653-8	BRUSH HOLDER 6.5-13.5		2	*		
C11	643536-2	BRUSH HOLDER 6.5X13.5	<	2		dr	
013	815F96-2	UC3051A NAME PLATE		1			
014	233173-6	pružina UC3020A-Serie		1			
015	416178-3	aretační tlačítko UC3020A=old22 5144010		1	*		
015-1	413B17-0	LOCK OFF BUTTON	<	1		areta	
016	650717-1	SWITCH TGC30B		1		vyp	
017	265995-6	šroub 4x18 = old 265941-9		1			
018	187901-0	HANDLE SET		1		rukoje	
C10	802G51-9	CAUTION LABEL		1			
018		INC. 28					
019	665894-6	POWER SUPPLY CORD 1.0-2-0.5		1		nap	
020	682540-6	ochr. průchodka 9,3-90=old6825 03-2		1		ochr. pr	
021	687124-5	držák kabelu		1		dr	
022	265995-6	šroub 4x18 = old 265941-9		2			
023	645105-5	kondenzátor = new 645006-7=ne w645200-1		1			
024	631719-6	elektronika ES-2130A =old97010 4021		1	*	elektronika ES-2130A =old970104021	
024-1	620M13-9	CONTROLLER	<	1			
025	419411-2	páčka vypínače ES-2135A =old22 6271010		1		p	

026	181044-0	uhlíky CB-153 = CB-152= old181041-6		1	*	uhl	
026-1	194985-1	CARBON BRUSH SET CB-153	O	1		uhl	
027	643650-4	víčko uhlíků		2	*	v	
027-1	643650-4	víčko uhlíků	O	2		v	
028	187901-0	HANDLE SET		1		rukoje	
C10	802G51-9	CAUTION LABEL		1			
028		INC. 18					
029	265995-6	šroub 4x18 = old 265941-9		6			
030	142282-9	TANK CAP COMPLETE		1		v	
031	454822-4	GEAR HOUSING COVER		1		pouzdro lo	
032	421959-2	gumové těsnění ES-2130A=old226114060		1		gumov	
033	454826-6	OIL TANK		1		olejov	
034	424611-1	CONNECTOR B		1		hadi	
035	424610-3	CONNECTOR A		1		hadi	
036	231975-4	pružina DCS230T/UC3020A=old021245060		1		pru	
037	416274-7	víčko DCS230T/UC3020A=old021245100		1		v	
038	454825-8	ROD		1			
039	233174-4	pružina ES-2130A=old225213060		1		pru	
040	142341-9	FRONT HAND GUARD COMPLETE		1		p	
C10	802K54-7	INDICATION LABEL		1			
041	158044-5	LINK PLATE COMPLETE		1		dr	
042	234005-0	COMPRESSION SPRING 9		1		pru	
043	213017-6	O RING 6		1		o krou	
044	454821-6	GEAR HOUSING		1		obal	
045	266041-8	šroub křížový 5103R = old 933526		4			
046	210028-2	BALL BEARING 606ZZ		1	*		
046-1	210206-4	BALL BEARING 606ZZ	O	1			
047	961006-2	segrovka S-10		1		segrovka S-10= old. 257408-1	
048	221427-3	WORM GEAR		1		n	
049	196419-0	OIL PUMP SET		1	*		
049		INC. 48			*		
049-1	142156-4	OIL PUMP COMPLETE	<	1	*	olejov	
049-2	142156-4	OIL PUMP COMPLETE	O	1		olejov	
050	424612-9	GROMMET		1		t	
051	265995-6	šroub 4x18 = old 265941-9		1			
052	227627-3	SPIRAL BEVEL GEAR 37		1		ozuben	
053	326373-6	SPINDLE		1		h	
054	210107-6	BALL BEARING 6001ZZ		1	*	lo	
054-1	210205-6	BALL BEARING 6001ZZ	O	1		lo	
055	454823-2	FRONT HANDLE		1		dr	
056	266041-8	šroub křížový 5103R = old 933526		2			
057	345651-5	ozubený doraz		1		ozuben	
058	266041-8	šroub křížový 5103R = old 933526		2			
059	319091-3	BEARING HOUSING		1		pouzdro lo	
060	266044-2	šroub 5x60		2			

061	267195-4	podložka DCS230T/UC3020A-Serie		1		podlo	
062	266026-4	šroub 4x12 křížový 5103R		1			
063	168426-3	pás brzdy = old 226213050		1		p	
064	125331-7	brzdový buben KPL. ES-2130A = old 226223111		1	*		
064-1	123886-6	BRAKE DRUM ASSEMBLY	O	1			
065	253215-0	796119		1			
066	259033-4	podložka		1		podlo	
067	266427-6	TAPPING SCREW 4X12		1			
068	454818-5	COVER		1		v	
069	227496-2	ozubené kolo UC3020A=old226213320		1		ozuben	
070	326372-8	ADJUST SCREW		1			
071	326310-0	ADJUST PIN		1			
072	266427-6	TAPPING SCREW 4X12		3			
073	142342-7	SPROCKET COVER COMPLETE		1	*		
073-1	183B54-5	SPROCKET COVER SET	<	1		kryt kompletn	
C10	142342-7	SPROCKET COVER COMPLETE		1			
073-1		INC. 67-73,75-78					
075	263002-9	vymezovací čep 4		1			
076	142665-3	DRIVE GEAR COMPLETE		1		nap	
077	454819-3	NUT COVER		1		o	
078	142235-8	NUT COMPLETE		1		up	
081	324685-1	hadička UC3020A-Serie		1		hadi	
A01	158024-1	držák=old970102050		1			
A02	165200-0	GUIDE BAR 12		1	*		
A02-1	165200-0	GUIDE BAR 12	O	1			
A03	419288-5	kryt pro UC3020/3520A		1	*		
A03-1	419288-5	kryt pro UC3020/3520A	O	1			
A04	196211-4	SAW CHAIN 12 SET		1	*		
A04-1	196211-4	SAW CHAIN 12 SET	O	1	*		
A04-2	191H10-7	SAW CHAIN 12 SET	O	1			
E01	805011-8	SOUND 103DB LABEL		1			
F03	196206-7	SAW CHAIN SET		1	*		

Prosím uveďte objednací číslo dílu v objednávce

Datum tisku 06. 11. 2024