



Model No.UC4041A 400MM ELECTRIC CHAIN SAW



Model No. UC4041A 400MM ELECTRIC CHAIN SAW



**Model No.UC4041A 400MM ELECTRIC CHAIN SAW**

Obj. č.	Obj. č.	Popis	Možn ost zá měny	Množ ství	Nový/ Starý	Poznámka 1	Poznámka 2
001	266326-2	šroub 4x18=new265995-6		3	*		
001-1	265B67-9	TAPPING SCREW 4X18	O	3			
002	454725-2	REAR COVER		1		kryt ES34TLC ES39TL C ES43TLC UC3041A UC3541A UC4041A	
003	191972-1	uhlíky CB-132 = old CB-115, 6601 91972		1	*		
003-1	194984-3	CARBON BRUSH SET CB-132	O	1		uhl	
004	682211-5	guma		2		guma	
005	815A97-0	UC4041A NAME PLATE		1			
006	424600-6	FRONT GRIP		1		p	
007	266388-0	TAPPING SCREW 5X16		1	*		
007-1	265D74-4	TAPPING SCREW 5X16	O	1			
008	253807-5	podložka 5		1		podlo	
009	142279-8	FRONT HAND GUARD COMPLETE		1		p	
C10	802K54-7	INDICATION LABEL		1			
010	231640-5	pružina		1		pru	
011	187869-0	HOUSING SET		1		obal stroje UC3041A UC3541A UC4041A	
C10	802G51-9	CAUTION LABEL		1			
011		INC. 62					
012	650577-1	SWITCH SD-006-BB2AA-AA		1		vyp	
013	650716-3	SWITCH TGC31B		1		vyp	
014	233173-6	pružina UC3020A-Serie		1	*		
014-1	233194-8	Druckfeder 4	O	1		pru	
015	416178-3	aretační tlačítko UC3020A=old22 5144010		1	*		
015-1	413B17-0	LOCK OFF BUTTON	<	1		areta	
016	455185-1	SWITCH LEVER		1		p	
017	645149-5	NOISE SUPPRESSOR		1		kondenz	
018	266326-2	šroub 4x18=new265995-6		2	*		
018-1	265B67-9	TAPPING SCREW 4X18	O	2			
019	687124-5	držák kabelu		1		dr	
020	682540-6	ochr. průchodka 9,3-90=old6825 03-2		1	*	ochr. pr	
020-1	682574-9	průchodka=old225152010	O	1		pr	
021	665876-8	POWER SUPPLY CORD 1.0-2-0.6		1		kabel	
022	210029-0	BALL BEARING 608ZZ		1			
023	681644-1	izolační podložka		1		izola	
024	594538-0	stator UC3020A		1	*		
C10	654069-2	Receptacle		2	*		
C20	654208-4	RECEPTACLE		1	*		
024-1	593869-4	FIELD ASS'Y 220-240V	O	1	*	stator= old594538-0	
C10	654069-2	Receptacle		2	*		
C20	654208-4	RECEPTACLE		1	*		
024-2	590103-3	FIELD ASS'Y 220-240V	O	1	*		
C10	654086-2	RECEPTACLE		2	*		
C20	654199-9	RECEPTACLE		1	*		
024-3	593869-4	FIELD ASS'Y 220-240V	O	1		stator= old594538-0	
C10	654069-2	Receptacle		2			

C20	654208-4	RECEPTACLE		1		
025	266389-8	TAPPING SCREW 5X70		2	*	
025-1	265D35-4	TAPPING SCREW 5X70	O	2		
026	513893-1	ARMATURE ASS'Y 220-240V		1	*	
026		INC. 22,23,29			*	
026-1	511A83-6	ARMATURE ASS'Y 220-240V	S	1		rotor ES34TLC = old 511A83-6
026-1		INC. 22,23,29				
028	419238-0	deska vzduchového chlazení UC3020A-Serie		1		deska vzduchov
029	211061-7	kuličkové ložisko 6000LLB		1		kuli
030	227153-2	pastorek 12 UC3020A-Serie		1		pastorek 12 UC3020A-Serie = old 660227153
031	931403-6	matka M8		1		matka M8
032	142282-9	TANK CAP COMPLETE		1		v
034	454729-4	OIL TANK		1		olejov
037	424602-2	OIL TUBE		1		hadi
038	231975-4	pružina DCS230T/UC3020A=old021245060		1		pru
039	416274-7	víčko DCS230T/UC3020A=old021245100		1		v
040	268238-5	PIN 5		1		
041	158047-9	deska UC3020A-Serie		1		deska UC3020A-Serie
042	233175-2	přítlačná pružina		1		p
044	266326-2	šroub 4x18=new265995-6		1	*	
044-1	265620-9	TAPPING SCREW FLANGE 4X18	S	1		
045	267195-4	podložka DCS230T/UC3020A-Serie		1	*	podlo
046	168321-7	BRAKE BAND		1		p
047	346739-4	BRAKE RING		1		krou
048	231817-2	pružina 5 UC3020A = 660231817ES		1		pru
049	454720-2	BEARING HOUSING		1	*	sk
049-1	413J59-2	BEARING HOUSING	S	1		pouzdro lo
050	213017-6	O RING 6		1		o krou
051	266326-2	šroub 4x18=new265995-6		4	*	
051-1	265B67-9	TAPPING SCREW 4X18	O	4		
052	424601-4	CONNECTOR		1		kryt ES39TLC
053	135615-5	SPUR GEAR 43 ASS'Y		1		hnac
055	210106-8	kuličkové ložisko		1		kuli
056	961006-2	segrovka S-10		1		segrovka S-10= old. 257408-1
057	210033-9	ložisko 696ZZ		1		lo
058	326359-0	ROD		1		ty
060	266326-2	šroub 4x18=new265995-6		2	*	
060-1	265B67-9	TAPPING SCREW 4X18	O	2		
061	345651-5	ozubený doraz		1		ozuben
062	187869-0	HOUSING SET		1		obal stroje UC3041A UC3541A UC4041A
C10	802G51-9	CAUTION LABEL		1		
062		INC. 11				
063	266326-2	šroub 4x18=new265995-6		7	*	
063-1	265B67-9	TAPPING SCREW 4X18	O	7		

064	221526-1	řetězka UC3520A		1		
065	259036-8	STOP RING E-8		1		krou
066	266007-8	Tapping Screw Bind PT3x1=old320266007		3		Tapping Screw Bind P T3x1=old320266007
067	454727-8	TENSION COVER		1		kryt nap
068	454726-0	DIAL 30		1		regula
069	326360-5	SHAFT		1		h
070	227496-2	ozubené kolo UC3020A=old226213320		1		ozuben
071	227496-2	ozubené kolo UC3020A=old226213320		1		ozuben
072	324620-9	šroub UC3020A = old 226213310		1		
073	346740-9	TENSION SLIDE		1	*	
073-1	346859-4	TENSION SLIDE	<	1		nap
074	424603-0	GROMMET		1		
075	196419-0	OIL PUMP SET		1	*	
075		INC. 76			*	
075-1	142156-4	OIL PUMP COMPLETE	<	1	*	olejov
075-2	142156-4	OIL PUMP COMPLETE	O	1		olejov
076	221427-3	WORM GEAR		1		n
077	266326-2	šroub 4x18=new265995-6		1	*	
077-1	265B67-9	TAPPING SCREW 4X18	O	1		
078	266427-6	TAPPING SCREW 4X12		3		
079	142281-1	SPROCKET COVER COMPLETE		1		krytES34TLC ES39TLC ES43TLC UC3041A UC3541A a UC4041A
C10	802E36-3	INDICATION LABEL		1		
080	454728-6	COVER		1		kryt
081	142235-8	NUT COMPLETE		1		up
082	804G74-3	SOUND 104DB LABEL		1		
A01	158024-1	držák=old970102050		1		
A02	165247-4	GUIDE BAR 16		1	*	
A02-1	165247-4	GUIDE BAR 16	O	1		
A03	419242-9	kryt řetězu pro UC4020A		1	*	kryt li
A03-1	419242-9	kryt řetězu pro UC4020A	O	1		kryt li
A04	196742-3	SAW CHAIN SET		1	*	
A04-1	511492756	SAW CHAIN 3/8LP.050" L56 CC D	O	1	*	
A04-2	531291656	SAW CHAIN 16"	X	1	*	
A04-3	196742-3	SAW CHAIN SET	O	1	*	
A04-4	191H03-4	SAW CHAIN 16 SET	O	1		

Prosím uveďte objednáací číslo dílu v objednávce

Datum tisku 06. 11. 2024